



CONCRETE RETARD COAT FOR HORIZONTAL SURFACES

DESCRIPTION:

Concrete Retard Coat For Horizontal Surfaces is a waterbased solution which is applied directly to a freshly placed concrete flatwork surface to retard the set of the surface cement to obtain an exposed aggregate surface.

USES:

Concrete Retard Coat For Horizontal Surfaces is a liquid that when sprayed on fresh soft concrete will retard the cement and expose the aggregate to produce a three dimensional surface. Concrete Retard Coat will retard the set of the surface cement between 12 to 24 hours after application and when applied as directed. The amount of retardation will be influenced by the concrete setting time which, in turn, is influenced by air temperature and humidity. Concrete Retard Coat will only retard the surface cement and will not retard or "kill" the set of the mix.

LIMITATIONS:

Concrete Retard Coat For Horizontal Surfaces may only be applied to concrete flatwork. Do not apply to vertical formwork, use Concrete Retard Coat For Vertical Surfaces. Concrete Retard Coat is to be applied to fresh concrete surfaces only. Do not apply when rain is anticipated within 12 hours or application, when surface is below 0°C, or when air temperature is above 25°C.

Using the mix design, prepare a test batch of concrete, lay the concrete and apply Concrete Retard Coat. It is recommended that in all applications that a test be conducted. It is also recommended that the work on exposed surfaces is always started as early as possible and to remain with the surface until Concrete Retard Coat is removed. If very small aggregate is used, it is important not to start the wash off too early to prevent bare spots. It is recommended that for concrete mixes that are going to be treated with Concrete Retard Coat, the mix design should be enriched by 20 percent more stones.

TECHNICAL DATA:

Typical Properties

| | |
|----------------|-----------------------|
| Colour | Light Blue Liquid |
| Weight | 2.17 pounds per Litre |
| Viscosity | Sprayable |
| Freezing Point | 0°C |
| Boiling Point | 100°C |

REV. 08/18/97

INSTALLATION INSTRUCTIONS:

Place the concrete (It is recommended that the mix design is enriched with 20% more stone than the standard mix). Wood float the surface to cover all stones.

DIRECTIONS:

Stir Concrete Retard Coat before application. After concrete finishing is complete, apply Concrete Retard Coat just as the surface water disappears. Apply at the specified application rate by using a brush, roller or low pressure sprayer. Protect the treated surface from wind, rain or high overhead sun. Re-apply Concrete Retard Coat to any sloping surface where run off may have occurred. When concrete's compressive strength reaches 7MPa (1000 psi) (between 12 to 24 hours), begin to expose the surface. Using a water broom or a stiff broom and hose, start washing down the surface to remove the Concrete Retard Coat. DO NOT leave material on the concrete indefinitely. As the amount of retardation desired is a personal preference, and timing of retardation is subject to many variables, it is recommended that the applicator stay with the surface and remove the Concrete Retard Coat at the exposure relief required or specified.

RATE OF APPLICATION:

Apply Concrete Retard Coat For Horizontal Surfaces as follows:

| | |
|---------------------|---|
| Surface Profile | Rate of Application |
| Average Retardation | 5.0m ² /L (225 ft ² /gal) |
| Deep Retardation | 2.5-3.5m ² /L (100-160 ft ² /gal) |

CLEAN UP:

Clean tools and equipment with water. Clean hands and skin with soap and water.

PACKAGING:

Concrete Retard Coat is packaged in 4 Litre and 20 Litre containers.

FIRST AID:

Contains methanol. Use in well ventilated areas only. Keep away from eyes. Use goggles during application. If in contact with eyes, flush with water immediately for fifteen minutes. Call a physician. Avoid prolonged contact with skin. Use protective clothing and gloves. Wash thoroughly after using or before smoking or eating. If swallowed, give patient 1 to 2 glasses of water. Do not induce vomiting. Call physician immediately. Keep out of reach of children.

Seller warrants that the product described on the face hereof has been manufactured of selected raw materials by skilled technicians. Neither seller nor manufacturer shall be responsible for any claims resulting from the failure to utilize the product in the manner in which it was intended and in accordance with instructions provided for use of product. The only obligation of either the seller or manufacturer shall be to replace any quantity of this product which proved to be defective. Neither seller nor manufacture assumes any liability, loss, or damage resulting from use of this product.



CONCRETE RETARD COAT FOR VERTICAL SURFACES

DESCRIPTION:

Concrete Retard Coat For Vertical Surfaces is an emulsion which is applied to concrete forms to retard the set of the surface cement to obtain an exposed aggregate surface.

USES:

Concrete Retard Coat For Vertical Surfaces is a liquid that when sprayed on wood or steel formwork will retard the cement and expose the aggregate to produce a three dimensional surface. The amount of retardation will be influenced by the concrete formwork strip/wash time which, in turn, is influenced by air temperature and humidity. Concrete Retard Coat will only retard the surface cement and will not retard or "kill" the set of the mix.

LIMITATIONS:

Concrete Retard Coat For Vertical Surfaces may only be applied to concrete formwork. Do not apply to formwork that will be subject to extreme weather conditions. Do not apply to flat or fresh concrete; use Concrete Retard Coat For Horizontal Surfaces. Do not apply when surface is below 0°C (32°F) or when air temperature is above 25°C.

TECHNICAL DATA:

Typical Properties

| | |
|----------------|-------------------|
| Colour | Light Blue Liquid |
| Viscosity | Sprayable |
| Freezing Point | 0°C |
| Boiling Point | 100°C |

INSTALLATION INSTRUCTIONS:

When new or uncoated forms are to be used, coat form with Concrete Release Agent, before applying first coat of Concrete Retard Coat For Vertical Surfaces. Prior to commencement of the job, an actual field sample form should be made. A test using a proposed mix design should be placed in the field sample form treated with Concrete Retard Coat and stripped/washed at 24, 30 and 36 hours to satisfy which penetration depth is acceptable. It is recommended that work on vertical exposed surfaces be done to allow sufficient time the next day to strip the form and wash the surfaces.

DIRECTIONS:

Stir Concrete Retard Coat before application. Product will settle during storage, a gentle agitation or stirring will re-emulsify the mixture. Apply Concrete Retard Coat to form by using a brush, roller or low pressure sprayer. First coat should be applied lightly. Check adhesion before applying second coat. Apply a heavy, uniform second coat as evenly as possible. Allow second coat to dry thoroughly for 2-4 hours. Protect coated forms from extreme weathering. Place Concrete (it is recommended a mix design that is enriched with at least 20% more stone than the standard mix). Forms should be removed in 24 hours. After stripping forms, remove retarded concrete immediately. If small aggregate is used, it is important not to start wash off too early to prevent bare spots. Use a water jet followed by brushing.

RATE OF APPLICATION:

Apply Concrete Retard Coat for vertical surfaces at 3.2 m²/litre (145ft²/gal).

CLEAN UP:

Clean tools and equipment with water. Clean hands and skin with soap and water.

PACKAGING:

Concrete Retard Coat is packaged in 4 litre and 20 litre containers.

FIRST AID:

Contains methanol. Use in well ventilated areas only. Keep away from eyes. Use goggles during application. If in contact with eyes, flush with water immediately for fifteen minutes. Call a physician. Avoid prolonged contact with skin. Use protective clothing and gloves. Wash thoroughly after using or before smoking or eating. If swallowed, give patient 1 to 2 glasses of water. Do not induce vomiting. Call physician immediately. Keep out of reach of children.

REV 08/18/97



FAST DRY CONCRETE RETARD COAT FOR VERTICAL SURFACES

DESCRIPTION:

FAST DRY CONCRETE RETARD COAT is an alcohol based retardant solution which is applied to concrete forms to retard the set of the surface cement to obtain an exposed aggregate surface. It is thick enough to adequately coat vertical surfaces and is designed for fast drying.

USES:

Fast Dry Concrete Retard Coat For Vertical Surfaces is a thick liquid that when sprayed on wood or steel formwork will retard the cement and expose the aggregate to produce a three dimensional surface. The amount of retardation will be influenced by the concrete formwork strip/wash time which, in turn, is influenced by air temperature and humidity. Concrete Retard Coat will only retard the surface cement and will not retard or "kill" the set of the mix.

LIMITATIONS:

Concrete Retard Coat For Vertical Surfaces may only be applied to concrete formwork. Do not apply to formwork that will be subject to extreme weather conditions. Do not apply to flat or fresh concrete; use Concrete Retard Coat For Horizontal Surfaces. Do not apply when surface is below 0°C (32°F) or when air temperature is above 25°C.

TECHNICAL DATA:

Typical Properties

| | |
|-----------|--------------------|
| Colour | Red Viscous Liquid |
| Viscosity | Sprayable |

INSTALLATION INSTRUCTIONS:

When new or uncoated forms are to be used, coat form with Concrete Form Release Agent, before applying first coat of Concrete Retard Coat. Prior to commencement of the job, an actual field sample form should be made. A test using a proposed mix design should be placed in the field sample form treated with Concrete Retard Coat and stripped/washed at 24, 30 and 36 hours to satisfy which penetration depth is acceptable. It is recommended that work on vertical exposed surfaces be done to allow sufficient time the next day to strip the form and wash the surfaces.

DIRECTIONS:

Stir Concrete Retard Coat before application. Product will settle during storage, a gentle agitation or stirring will re-emulsify the mixture. Apply Concrete Retard Coat to form by using a brush, roller or low pressure sprayer. First coat should be applied lightly. Check adhesion before applying second coat. Apply a heavy, uniform second coat as evenly as possible. Allow second coat to dry thoroughly for 1/2 hour. Protect coated forms from extreme weathering. Place Concrete (it is recommended a mix design that is enriched with at least 20% more stone than the standard mix). Forms should be removed in 24 hours. After stripping forms, remove retarded concrete immediately. If small aggregate is used, it is important not to start wash off too early to prevent bare spots. Use a water jet followed by brushing.

RATE OF APPLICATION:

Apply Concrete Retard Coat for vertical surfaces at 3.2 m²/litre (120ft²/US gal).

CLEAN UP:

Clean tools and equipment with water. Clean hands and skin with soap and water.

PACKAGING:

Concrete Retard Coat is packaged in 1 US Gallon containers.

FIRST AID:

Contains methanol. Use in well ventilated areas only. Keep away from eyes. Use goggles during application. If in contact with eyes, flush with water immediately for fifteen minutes. Call a physician. Avoid prolonged contact with skin. Use protective clothing and gloves. Wash thoroughly after using or before smoking or eating. If swallowed, give patient 1 to 2 glasses of water. Do not induce vomiting. Call physician immediately. Keep out of reach of children.

REV 06/26/03